

Primer (see footnote)	VOC (g/l)	AD FIREFILM III	AD FIREFILM III C	THERMO- SORB	Nullifire S605	Nullifire S606	THERMO- LAG 3000, 2000, 440
Carbocoat 115 ⁽²⁾	419	Acceptable	Acceptable		Acceptable	Acceptable	
Carbocoat 115 VOC ⁽²⁾	340	Acceptable	Acceptable	Acceptable	Acceptable		Acceptable
Carbocoat 150 UP ⁽²⁾	409	Acceptable	Acceptable	Acceptable	Acceptable	Acceptable	
Carbocoat 150 HG ⁽²⁾	348	Acceptable	Acceptable	Acceptable	Acceptable	Acceptable	
Carbocoat OEM ⁽⁵⁾ Universal Primer	407			Acceptable			
Carbocrylic 120 ⁽²⁾⁽³⁾	98	Acceptable	Acceptable		Acceptable	Acceptable	
Carbocrylic 3350 ⁽²⁾⁽³⁾	250	Acceptable	Acceptable				
Carbocrylic 3358 ⁽²⁾	153	Acceptable	Acceptable				
Carbocrylic 3359 DTM ⁽²⁾	217	Acceptable	Acceptable	Acceptable			
Carboguard 635 ⁽¹⁾	296	Acceptable	Acceptable	Acceptable	Acceptable	Acceptable	
Carboguard 888 ⁽¹⁾	330			Acceptable	Acceptable	Acceptable	Acceptable
Carboguard 890 ⁽¹⁾	214						Acceptable
Carboguard 893 ⁽¹⁾	195				Acceptable	Acceptable	
Carboguard 893 SG LT ⁽¹⁾	318	Acceptable	Acceptable				Acceptable
Carboguard 893 SG ⁽¹⁾	336	Acceptable	Acceptable	Acceptable			Acceptable
Carboguard 1340 ⁽¹⁾⁽³⁾	95				Acceptable	Acceptable	
Carbomastic 15 ⁽¹⁾	88			Acceptable	Acceptable	Acceptable	Acceptable
Carbomastic 242 ⁽¹⁾	327						Acceptable
Carbozinc 11 ⁽²⁾	479				Acceptable	Acceptable	
Carbozinc 858 ⁽¹⁾	303						Acceptable
Carbozinc 859 ⁽¹⁾	326				Acceptable	Acceptable	Acceptable
Carbozinc 11/ Carboguard 893 SG ⁽¹⁾	479 336						Acceptable
Galoseal WB ⁽²⁾	99				Acceptable	Acceptable	
Pyrocote 1340 ⁽¹⁾⁽³⁾	95				Acceptable	Acceptable	
Rustbond ⁽¹⁾⁽⁴⁾	85	Acceptable	Acceptable	Acceptable	Acceptable	Acceptable	Acceptable
Rustbond FC ⁽¹⁾	227	Acceptable	Acceptable		Acceptable	Acceptable	

Note:

- (1) Designates primers that require a minimum 24 hr. cure @ 70 °F before applying intumescent fireproofing.
- (2) Designates primers that require a minimum 7 day cure @ 70 °F before applying intumescent fireproofing.
- (3) Designates primers that can only be used as tie-coat primers under intumescent fireproofing.
- (4) For exterior applications, contact Carboline Technical Service before applying Rustbond.
- (5) Designates primers that require a minimum 4 hr. cure @ 70 °F before applying intumescent fireproofing.